

PIG Pipe Filter Sock

This report is offered as a guide and was developed from information which, to the best of New Pig's knowledge, was reliable and accurate. Due to variables and conditions of application beyond New Pig's control, none of the data shown in this guide is to be construed as a guarantee, expressed or implied. New Pig assumes no responsibility, obligation, or liability in conjunction with the use or misuse of the information.



New Pig

One Pork Avenue
Tipton, PA 16684-0304

newpig.com

North America: **1-800-468-4647**

Europe: **+31 (0)76 596 92 50**

China: **+86-21-400 921 5178**

UK: **0800 919 900**

Outside North America: **+1-814-684-0101**

PIG, PIG logo are registered trademarks in USA and other countries. See tm.newpig.com

503313/366185

PIG Pipe Filter Sock

Installation



1. Thread hose clamp through the green loops.



2. Place mouth of Pipe Filter Sock over discharge hose or pipe.



3. Fasten hose clamp tightly with a 5/16" nut driver.



4. Tuck remaining hose clamp into green loops to secure.



5. Extend product completely so it isn't folded over on itself.

Inspection & Maintenance

- Monitor the product regularly for any damage, loosening of the hose clamp, or changes in filtration
- Test filtered effluent to determine if product is filtering at maximum efficiency
- Reduced flow may indicate that the product needs to be replaced
- Dispose of the product in compliance with local, state, federal and country regulations.



New Pig

One Pork Avenue
Tipton, PA 16684-0304

newpig.com

North America: **1-800-468-4647**

Europe: **+31 (0)76 596 92 50**

China: **+86-21-400 921 5178**

PIG, PIG logo are registered trademarks in USA and other countries. See tm.newpig.com

UK: **0800 919 900**

Outside North America: **+1-814-684-0101**

503313/366185